





iPod Touch 4th Generation Blank Screen

This is a guide to try and short the battery if your device is dead after a screen repair or is not recognised by iTunes

Written By: con



Step 1 — iPod Touch 4th Generation Blank Screen



- He in the picture pointed out by the screw drivers are first the battery terminal you want to ground and second the dock connector metal you want to ground against

Step 2



- Now touch battery terminal 3 and the dock connector metal with the metal part of a screw driver together this in turn should short the battery and get ipod back to life

Step 3



- Now when you reattach the screen get your wall charger and turn it on and plug into device.. Now you should see the apple sign

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 11:02:49 PM.